


Sound Setting

VC-MDx Recorder


Version 2201

This document describes the sound setting in Windows of a standard VC-MDx recorder. The VC-MDx application requires an allocation to the used output device. If for any reason an additional sound device was connected or recognised the sound setting must be adjusted.


1. Right click sound properties




2. Click on „Open Sound settings“



- 3. Scroll down and click “app volume device preferences” on advanced sound options



- 4. Select the Audio device on output



*** END OF DOCUMENT ***